

LUNA 4DUAL+



INSTALLATION GUIDE

1 Table of contents

*Welcome to this installation guide dedicated to your first use of the LUNA 4Dual.
Please follow all the instructions carefully to ensure the success of the installation.*

| | |
|---|-----------|
| PACK CONTENT | 2 |
| INSTALLATION | 3 |
| CONNECTING TO THE MYATTENTIVE PLATFORM | 5 |
| PAIRING A DEVICE | 6 |
| REMOVING A DEVICE | 7 |
| TEST PHASE | 8 |
| TYPES OF COMMANDS | 9 |
| LIGHT INDICATORS | 10 |

2 Pack Content



1 LUNA 4DUAL+

2 PENDANT

3 ETHERNET CORD

4 NANO SIM CARD AND EXTRACTOR TOOL


5 POWER SUPPLY

Use only the provided version



3 Installation

WARNING: The LUNA 4DUAL+ is not compatible with POE (Power over Ethernet). It should not be connected behind a POE switch/router, as this may cause irreversible damage.

1. Remove the cap **A** with the SIM extractor tool, (if the SIM card is present, proceed to step 3).
2. Insert the **SIM** card and lock the cap.
3. If your **SIM** card has a PIN code, please enter it using the device's programming software.
4. Connect the **provided power supply** in the port **POWER**, then plug it into an easily accessible electrical AC outlet.
5. Lock the power cable using the anti-traction hook (**B**).
6. Connect the provided **ETHERNET cable** on the port , then plug it into an Ethernet port on the internet box (ADSL/fiber).



7. Set the **ON/OFF switch** to **ON**, 6 successive beeps indicates the start of the initialization.

***Wait a few minutes during the setup phase.
The initialization phase will be indicated by 3 beeps.
If an error occurs (5 strident beeps), repeat the previous step.***

After installation, leave the LUNA 4Dual+ plugged into the power outlet for at least 24 hours to ensure the battery backup operates correctly in case of a power outage.





4 Connecting to the MyAttentive platform

The  LED on the LUNA 4Dual+ and the front light  flashes.
The setup is complete when the front light  is steady and the  light has been off for several seconds.



5 Pairing a device

1. To initiate the pairing mode, press and hold the 📞 and ✉️ buttons simultaneously until you hear a beep. The green/blue lights are flashing.
2. Press the button on the [pendant](#) or any other [peripheral device button](#) to register it. Success in this step is indicated by the 📞 button flashing and a sound signal. You can perform a range test by pressing any of the devices. If you hear a sound signal, it means that it has been successfully paired.
3. Press and hold the 📞 and ✉️ buttons again until the sound signal to exit the pairing mode.
4. The LUNA 4Dual+ will synchronize with the Myattentive platform. The front light 🟡 will flash throughout this phase.



6 Removing a device

1. Initiate the pairing mode by pressing the 📞 and ✉️ buttons until you hear a beep. The green/blue lights are flashing.
2. Press and hold the 📶 button for 10 seconds until you hear a sound indicating the dissociation of all devices.
3. Press and hold the 📞 and ✉️ buttons again until the sound signal to exit the pairing mode.
4. The LUNA 4Dual+ will synchronize with the Myattentive platform. The front light 🟡 will flash throughout this phase.

7 Test phase

Press the button on the pendant provided with the LUNA 4Dual+ to trigger an emergency or concierge call.



8 Types of commands

FRIENDLY CALL

- Press this button to call the pre-registered number.
- Press again to hang up.

ABSENCE MODE


- To activate the ABSENCE mode, press and hold until you hear a beep. This action will notify your departure.
- Press again to notify when you are back home.

EMERGENCY CALL

- Press the central button or the pendant button to contact the telecare call center.

VOCAL MESSAGES

- Press this button to listen the recorded messages.



9 Light Indicators



LIGHT STAYS ON

ABSENCE mode activated or friendly call in progress.

FLASHING

Dialing of a friendly call.



LIGHT STAYS ON

Emergency call in progress.

FLASHING

The device is communicating with the telecare center's server.



ORANGE LIGHT

Ethernet cable unplugged.

GREEN + ORANGE LIGHT

Ethernet cable connected and functional.



FLASHING

Pairing of a radio device or connected object.

SIMULTANEOUS FLASHING

Loss of ethernet connection.



LIGHT STAYS ON

Device connected to mains supply.

SLOW FLASHING

Power outage and use of the transmitter in battery mode.

FLASHING

The transmitter is communicating and synchronizing with the ATTENTIVE platform.



4G NETWORK SIGNAL QUALITY

- Maximum level
- Average level
- Low level

OTHERS

- Radio network search in progress
- SIM card missing

LUNA 4DUAL+ Technical Features



USE

Admissible humidity: 90% (Relative humidity)
Maximum permissible ambient
temperature for product use : 40°C
Warranty: 2 years



DIMENSIONS

274 mm x 125 mm x 58 mm



POWER

Ni-MH Rechargeable Battery 7.2 V, 750 mAh
Autonomy: 3 days
Power supply: INPUT: 100-240V ~ 0.2A Max 50/60Hz
OUTPUT: 12V \equiv 0.5A



DECLARATION OF CONFORMITY

SOLEM Electronique declare that LUNA 4DUAL+ complies
with the essential requirements of the European Directives:
2014/53/UE (RED) Directive,
and the product standard for Social Alarm Systems:
EN 50134-2.
RoHS Directive 2011/65/EU & Directive amendment
(EU)2015/863

STANDARDS APPLIED

CEM : EN 301 489-1 v2.2.3 / EN 301 489-3 v2.1.1 / EN
301 489-17 v3.2.4 / EN 301 489-19 v2.1.1 / EN Draft
301489-52 v1.1.0 / EN 55032 ed. 2015 + AC of 2016 /
EN 55035 ed. 2017

Electrical safety : EN 62368-1 (2014) & A11 (2017)

Radio (869MHz) : EN 300 220-3-1 v2.1.1

EMF : EN 62311 (2008), recommandation 1999/519/CE

Wi-Fi : EN 300 328 v2.1.1 & EN/ETSI 301 893 v2.1.1

Bluetooth® : EN 300 328 v2.2.2

Modem 4G/3G/2G : EN/ETSI 301 511 v12.5.1 & TS 151
010-1 v13.4.0 (2G) / EN 301 908-1 v13.1.1 (3G) / EN
301908-1 v13.1.1 (4G)

RF-ID : EN 300 330-1 v2.1.1

Clapiers, January 10th 2023

Olivier AUSSILLOUS
Industrial Director

PLEASE READ THE FOLLOWING SAFETY INSTRUCTIONS THOROUGHLY BEFORE THE FIRST USE OF YOUR LUNA 4DUAL + BE SURE TO STRICTLY FOLLOW ALL PRECAUTIONS FOR USE.

LUNA 4Dual + should be only installed indoor.













Install your product so that the socket outlet is near the LUNA. The power outlet is a disconnect device, in case of a problem, it must be easily accessible at all times. Make sure that the power outlet on which your power supply transformer is connected has overcurrent and short circuit protection such as a 16A circuit breaker.

Use only the power supply supplied with the product INPUT: 100-240V ~ 0.2A Max 50/60Hz **OUTPUT:** 12V  0.5A

Maximum permissible ambient temperature for product use: 40°C

Best cleaning practices: Use exclusively a soft cloth, lightly moistened with water, do not clean electrical connections, do not use solvents, cleaning agents or abrasive detergents. Avoid direct exposure of the product to direct sunlight.

WARNING: Risk of explosion if battery is replaced by an incorrect type. Discard empty battery according to local regulations.

| | |
|---|--|
| PROG | Mini-USB connector: service connector |
| POWER | Power connector: connector made for connecting the power supply supplied with the LUNA 4G 12V  0.5A. |
|  | The symbol «CE» indicates that this appliance complies with the European standards on safety, health, environment and user protection. Devices with the «CE» symbol are intended for sale in Europe. |
|  | This symbol means that electronic and electrical appliances, which have reached the end of their working life, must be collected and disposed of separately in all European countries. Do not put the battery in your household trash. |
| C1 | This symbol means that the product complies with radio reception (Class 1) following the ETSI EN 300 220-2 v2.4.1 standard. |
| ~ | This symbol means that the supply voltage is an AC voltage. |
|  | This symbol means that the supply voltage is a DC voltage. |
|  | This symbol means that the power supply is intended for indoor use only. |
|  | This symbol means that the power supply is rated to Class 2 (double insulation). |
|  | This symbol means that the output of the external power supply is level 6. |
|  | This symbol is the certification mark of the food (DE lab logo). |
|  | This symbol warns of electrical danger. |
|  | This symbol indicates that the manufacturer complies with the RoHS regulations in force. |
|  | This symbol means the polarity of the DC supply voltage. |
|  | RJ45 network cable plug. |

BATTERY INSTRUCTIONS :

- The maximum operating altitude is 2000m. A battery subjected to extremely low air pressure can cause an explosion or leak of flammable liquid or gas.
- Replacing the battery with a different reference or model poses a risk.
- If replacing the battery, use only the same type of battery.
- Batteries and accumulators contain highly toxic substances. It is important not to dispose of them anywhere and in no case in the household waste bin. All used batteries and accumulators must be deposited in specific containers in order to be recycled.
- Exposing the battery to very high temperatures can cause an explosion.

| PIN# | Polarity |
|------|----------|
| + | Positive |
| - | Return |

